




Erbauer EBCP41
41.2cc Brush Cutter

Parts Manual



Part ID	Apelson PN	MPN	Part Description
Diagram 1 - Engine Assembly			
1	GP0000006886	20062709	SCREW - M5x20 \$\$\$
2	GP0000006887	20067769	AIRBOX COVER
3	GP0000006888	20055803	WASHER \$\$\$
4	GP0000006889	20058868	AIR FILTER
5	GP0000006890	20061072	SCREW - M5x45 \$\$\$
7	GP0000006891	20053970	AIRBOX HOUSING
8	GP0000006892	20054909	CARBURETTOR - WALBRO WT-1205
9	GP0000006893	20061082	SCREW - M5x25
10	20050665	20050665	RUBBER GASKET
11	GP0000006894	20070293	CARBURETTOR MOUNT
12	20055742	20055742	SCREW - ST4x10
13	GP0000006895	20051083	INLET GASKET
14	GP0000006896	20064903	CHOKE LEVER
15	GP0000006897	20082107	SHROUD
16	20054547	20054547	SCREW
17	GP0000006898	20067736	SPARK PLUG COVER
18	GP0000006899	20081276	SPARK PLUG - NGK CMR7H
19	GP0000006900	20081277	UPPER CASING
20	GP0000006901	20061124	SCREW - M5x14 \$\$\$
21	GP0000006902	20060942	SCREW - M4x12 \$\$\$
22	GP0000006903	20054011	REAR BRACKET
23	GP0000006904	20051174	BRACKET GASKET
24	GP0000006905	20054005	CYLINDER
25	GP0000006906	20054008	IGNITION COIL BRACKET
26	GP0000006907	20051089	IGNITION COIL ASSEMBLY
27	20054552	20054552	SCREW - M5x20
28	GP0000006908	C36.1106.0301	WIRE A
29	GP0000006909	C36.1106.0302	WIRE B
30	GP0000006910	20051085	EXHAUST GASKET
31	GP0000006911	20058857	EXHAUST HEAT SHIELD
32	GP0000006912	20070297	EXHAUST
33	GP0000006913	20061311	SCREW - M6x60
34	GP0000006914	20051084	HEAD GASKET
35	GP0000006915	20054013	COMPRESSION RINGS
36	20053105	20053105	CIRCLIP \$\$\$
37	GP0000006916	20062717	BEARING 10x13x16
38	GP0000006917	20054012	PISTON
39	GP0000006918	20054014	GUDGEON PIN
40	GP0000006919	20067739	FUEL TANK GUARD
41	GP0000006920	20055527	HEAT SHIELD
42	GP0000006921	20061112	SCREW - M5x16 \$\$\$
43	GP0000006922	20062708	CLUTCH BOLT
44	GP0000003624	20061467	WASHER \$\$\$
45	GP0000006923	20058862	CLUTCH ASSEMBLY
46	GP0000006924	20062716	WASHER \$\$\$
47	GP0000003621	20061348	FLANGED NUT - M8
48	GP0000006925	20051088	FLYWHEEL
49	20054566	20054566	LOCATING PIN

50	GP0000006926	20070315	OIL SEAL
51	GP0000006927	20053962	CRANK CASING (LH)
52	GP0000003014	20054571	BEARING
53	GP0000006928	20051087	CRANK CASE GASKET
54	GP0000006929	20061664	WOODRUFF KEY
55	GP0000006930	20070294	CRANKSHAFT ASSEMBLY
56	GP0000006931	20053959	CRANK CASING (RH)
57	20056600	20056600	OIL SEAL
58	GP0000006932	20061084	SCREW - M5x30
59	GP0000006933	20061431	WASHER \$\$\$
60	GP0000006934	20058865	STARTER CLUTCH
61	GP0000002925	20054561	WASHER \$\$\$
62	GP0000006935	20059254	STARTER COG
63	GP0000006936	20058870	STARTER ASSEMBLY - CLOCK SPRING
64	GP0000006937	20059251	STARTER ASSEMBLY - PULL CORD SPOOL
65	GP0000006938	20059252	STARTER ASSEMBLY - CLOCK SPRING HOUSING
66	20056498	20056498	STARTER ASSEMBLY - CLOCK SPRING
67	GP0000006939	20058871	STARTER ASSEMBLY - HOUSING
68	20054603	20054603	STARTER ASSEMBLY - EYELET
69	GP0000006940	20054676	STARTER ASSEMBLY - PULL CORD
70	20081175	20081175	STARTER ASSEMBLY - PULL CORD HANDLE
71 - Old	20054685	20054685	FUEL BREATHER VALVE
71 - New	GP0000003206	A45.0111.0200	FUEL BREATHER VALVE
72	GP0000006941	20054576	FUEL TANK ASSEMBLY - BREATHER TUBE
74	GP0000003208	20070348	FUEL TANK ASSEMBLY - FUEL PIPE GASKET
75	GP0000006942	20056635	FUEL TANK ASSEMBLY - FUEL DELIVERY TUBE
76	GP0000006943	20057176	FUEL TANK ASSEMBLY - FILLER CAP
77	GP0000006944	20057242	FUEL TANK ASSEMBLY - FILLER CAP SEAL
78	GP0000006945	20057244	FUEL TANK ASSEMBLY - CAP RETAINER
79	GP0000006946	20067782	FUEL TANK ASSEMBLY - TANK
80	GP0000006947	20053113	FUEL TANK ASSEMBLY - FILTER
81	GP0000003210	20054663	FUEL TANK ASSEMBLY - PIPE CLIP
82	GP0000006948	20067743	LOWER CASING
83	GP0000006949	20058869	CLUTCH DRUM
84	20054564	20054564	CIRCLIP
85	GP0000003014	20061639	BEARING
86	GP0000006950	20058856	PLASTIC BASE
87	GP0000006951	20053971	CLUTCH HOUSING
88	GP0000006952	20061548	CIRCLIP
89	GP0000006953	20070477	DAMPING COLLAR
90	GP0000006954	20054309	SHAFT COUPLER
91	GP0000006955	20061116	SCREW - M6x25
92	GP0000006956	20061550	CIRCLIP
93	GP0000006957	20060973	SCREW - M5x14
94	GP0000006958	20061393	NUT
95	GP0000006959	20058858	HEAT SHIELD

Diagram 2 - User Components

1	GP0000006961	20054025	DRIVE SHAFT
2	GP0000006962	20080982	DRIVE SHAFT TUBE
3	GP0000006963	20070383	VIBRATION DAMPER
4	GP0000006964	20059115	NEEDLE BEARING
5	GP0000006965	20081274	HANDLE BRACKET
6	GP0000006966	20067794	HANDLE BRACKET - SIDE PLATE
7	GP0000006967	20081275	HANDLE BRACKET - COVER PLATE
8	GP0000006968	20058874	HANDLE BRACKET - HARNESS BRACKET
9	GP0000006969	20067807	HANDLE BRACKET - BOTTOM COVER
10	GP0000006970	20061001	SCREW \$\$\$
11	20060978	20060978	SCREW \$\$\$
12	GP0000006971	20058878	SHOCK ABSORBER SPRING
13	GP0000006972	20070419	DAMPING SLEEVE (LOWER)
14	GP0000006973	20070420	DAMPING SLEEVE (UPPER)
15	GP0000006974	20059320	LOCKING BAND
16	GP0000006975	20061030	SCREW - M5x15
17	GP0000006976	20061396	NUT - M6
18	GP0000006977	20058875	WIRE CLAMP
19	GP0000006978	20054562	WASHER \$\$\$
20	GP0000006979	20053978	HANDLE BAR CLAMP - UPPER
21	GP0000006980	20053982	HANDLE BAR CLAMP - LOWER
22	GP0000006981	20079922	LOCKING KNOB
23	GP0000005317	20061278	HEX SCREW - M8x60
24	GP0000006982	20061543	WASHER \$\$\$
25	GP0000006983	20081001	HANDLE BAR
26	GP0000006984	20070415	HANDLE (LH)
27	GP0000006985	20059304	HANDLE CLAMP (LH)
28	GP0000006986	20061126	SCREW - M5x45
29	GP0000006987	20054558	NUT - M5
30	GP0000006988	20067381	TRIMMER HEAD GUARD
31	GP0000006989	20067392	TRIMMER HEAD GUARD BUMP STRIP
32	GP0000006990	20058298	TRIMMER WIRE BLADE
33	GP0000006991	20054542	SCREW \$\$\$
34	GP0000006992	20062724	SCREW \$\$\$
35	GP0000006993	20081278	TRIMMER HEAD GUARD BRACKET
36	GP0000006994	20062723	SCREW \$\$\$
37	20073764	20073764	SCREW - M6x14
39	GP0000006995	20051715	ANGLE GEAR
40	GP0000006996	30001300	ACCESSORY - TRIMMER HEAD ASSEMBLY
41	GP0000006997	20082829	ACCESSORY - BRUSH CUTTER BLADE - 30cm - 3T
42	GP0000006998	C36.1111.0300	CONTROL HANDLE - (RH)
42-14	GP0000006999	20050236	THROTTLE CABLE