


Cooker Hood
Model Number
NNVHS60UK
Parts Manual

Exploded Drawing



Spare Parts List

ID No	Part Number	Description	Qty
1	301039900336	OUTLET COVER	1
2	301031000020	V-FLAP	2
3	301030700011	OUTLET	1
4	301040700151	POWER CORD	1
5	201010201176	CAVITY ASSEMBLY (SET)	1
6	290010300074	PUSH BUTTON ASSEMBLY	1
7	201010800038	LAMP PLATE	1
8	301040200349	LED LIGHT	1
9	301030400027	RIGHT IMPELLER	1
10	301040600638	RIGHT MOTOR	1
11	301030300266	BLOWER	1
12	301030300264	MOTOR SCREW COVER	2
13	301030300232	WIND SHIELD	1
14	290010400001	TERMINAL BLOCK	1
15	301040100059	CAPACITOR	1
16	301030300267	WIRE COVER	1
17	399010800016	SPRING	2
18	301039900246	MOVABLE SPRING BLOCK OF GLASS BASE	2
19	301039900248	LEFT GLASS BASE	1
20	301039900245	LEFT GLASS SLEEVE	1
21	301039900247	RIGHT GLASS BASE	1
22	301039900244	RIGHT GLASS SLEEVE	1
23	301070500041	FRONT GLASS	1
24	301060100299	ALUMINIUM FILTER	2
25	301030900012	OUTLET ADAPTOR	1

Order assembly AA0000003359

Order assembly AA0000003360